





## Pharmacode Scanning Setup (Detailed)

BASIC SETUP INSTRUCTIONS		
Navigate to the Colour Code Page	From the main page press  > <b>STATION SETUP</b> ( <i>Button</i> )  > <b>COLOUR CODE</b> ( <i>Tab</i> )	 <p><b>Buttons</b> are generally found in the main window and perform various tasks such as 'Learn Code'.</p> <p><b>Tabs</b> are found across the top of most pages and are links to other pages.</p>
Input the Start scan & Stop scan dimensions	From the pharmacode page  > Select the <b>START SCAN</b> field ( <i>Field</i> ) > Input the dimension > Select the <b>END SCAN</b> field ( <i>Field</i> ) > Input the dimension > <b>SAVE CHANGES</b> ( <i>Button</i> )	 <p>These settings tell the controller where the code is positioned on the glue flap. Please allow 10mm either side of the barcode when setting these dimensions.</p> <p><b>Fields</b> are areas (spaces) which require a setting to be input.</p>
Ensure code setup is correct	From the pharmacode page  > <b>CODE SETUP</b> ( <i>Button</i> )  Default settings:  Thin Bar Width = <b>0.5 or 1.0</b> Thick Bar Width = <b>1.5 or 3.0</b> Thin Bar Min = <b>0.1</b> Code sim/Inverse code = <b>Off/On</b>  > <b>SAVE CHANGES</b> ( <i>Button</i> )	 <p>These settings tell the controller about the size of the printed barcode.</p> <p>To change any setting simple select the field and use the keypad to enter the new information.</p>
Ensure scanner is set to background colour  <b>(not required unless background colour has changed)</b>	At the barcode reading head  Inch a carton into the pre-break station so that the background colour is being 'seen' by the blue light spot.  Ensure LED lights indicate <b>A 1</b>  Lift the cover of the barcode scanner and press the <b>SET</b> button once.  Done.	 <p>Pharmacode setup is now complete.</p> <p>For more detailed barcode setting please contact W H Leary Service Department.</p>